

Frank Burton & Sons

333 West Broad St., Bridgeton, NJ, 08302
(856)-455-1202 (856)-453-1896 (Fax)
www.frankburtons.com

Project Tip

** This patch should be used for TEMPORARY repairs only. You should replace the damaged section of pipe as soon as possible.*

1. Cut a short piece of rubber hose aprox. 1"-2" long and carefully slice the hose lengthwise.

(Don't worry if the hose is not big enough to fit all the way around the copper pipe. It only has to cover the pipe where the pinhole is located.)

2. Wrap the hose around the copper pipe, making sure the hose covers the pinhole in the pipe.

3. Place a Stainless Steel hose clamp over the rubber hose DIRECTLY over where the pinhole is located. Tighten the hose clamp securely. This should force the rubber hose into the pinhole and temporarily stop the leak.

4. Call Frank Burton & Sons to have the section of Copper pipe replaced.

